



Brief guide to magnetic lock

The ORANKA beverage system offers you maximum product safety with its lockable container lid, in accordance with the Food Hygiene Regulation. The patented locking system is made exclusively from materials that can be cleaned hygienically in a dishwasher. The container lid is locked by two bolts which fit under the edge of the container when

the lid is in position. The locking bolts engage in this position with an audible click.

Please observe the following steps when removing the lid.

Further fruity information is available at www.oranka.com.

ORANKA. How practical.



- 1** Hold the inside edge of the lid with your index and middle finger to the left and right of the lock. You can then exert light pressure on the lock.



- 2** Place the magnetic key flat on the lock.



- 3** When the magnetic lock clicks, the bolts can be pulled out.



- 4** Pull the lock completely out until it stops with your thumb and index finger.



- 5** In this position you can remove the container lid. Otherwise the instructions in the "ORANKA Eskimo Quick Guide" apply.



- INFO** If you have any questions about the patented ORANKA beverage system, please contact your personal ORANKA customer manager. We will be happy to help.

ORANKA brand dispenser.

Brief guide to magnetic lock.